



ORIGINAL	SUPERIOR
POWER	POWER
⏠ / HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	📺 / SOURCE
MENU / LIST	-/--
DISPLAY	📺
🕒 / REPEAT	📺
📶 / TV/RADIO	📺
☰ / TEXT	☰
SKIP NEXT	P+
SKIP PREV	P -
UP / PR+	UP
DOWN / PR -	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
🎧 / RETURN	BACK
DUBBING	SLEEP
TV / DVD	TV/DTV
📶 / ZOOM	INFO
GUIDE	EPG
MARKER	FAV
OPEN / CLOSE	⬆️ / NET TV

ORIGINAL	SUPERIOR
PAUSE / STEP	⏸️
STOP	📺 / SMART
REC	RED
SCAN REW	GREEN
PLAY	YELLOW
SCAN FWD	BLUE
SEARCH	SHIFT+EXIT
DVD	SHIFT+1
HDD	SHIFT+2
THUMBNAIL	SHIFT+📺
RANDOM	SHIFT+📺
PIP	SHIFT+📺
CHP. ADD	SHIFT+📺
TITLE	SHIFT+INFO
RED / FAV	SHIFT+RED
GREEN / AUDIO	SHIFT+GREEN
YELLOW / SUBTITLE	SHIFT+YELLOW
BLUE / TIMESHIFT	SHIFT+BLUE

