



ORIGINAL	SUPERIOR
POWER	POWER
⦿ / AUDIO	MUTE
MENU/LIST	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV / INPUT	📺 / SOURCE
🏠 / HOME	-/--
DISPLAY	📺
ZOOM	📺
PIP	📺
⋮ / SUBTITLE	📺
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
🔊 / RETURN	BACK
TIMESHIFT	SLEEP
TV/DVD	TV/DTV
TITLE	INFO
CHP. ADD	EPG
MARKER	FAV

ORIGINAL	SUPERIOR
OPEN/CLOSE	⬆ / NET TV
PAUSE/STEP	⏸
STOP	■ / SMART
REC	RED
SCAN REW	GREEN
PLAY	YELLOW
SCAN FWD	BLUE
SEACH	SHIFT+EXIT
DVD	SHIFT+1
HDD	SHIFT+2
PR/CH+	SHIFT+ P+
PR/CH -	SHIFT+ P -
REPEAT	SHIFT+BACK
A - B	SHIFT+SLEEP
THUMBNAIL	SHIFT+TV/DTV
DUBBING	SHIFT+INFO
REC MODE	SHIFT+RED

