



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
 / AUDIO	MUTE
 / HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV/INPUT	 / SOURCE
LIST/MENU	-/--
DISPLAY	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
 / RETURN	BACK
TIME SHIFT	SLEEP
TV/DVD	TV/DTV
TITLE	INFO
SHOW VIEW	EPG
✓ / MARKER	FAV
OPEN/CLOSE	 / NET TV
PAUSE	
STOP	 / SMART

[illegible]