



ORIGINAL	SUPERIOR
POWER	POWER
⏻ / AUDIO	MUTE
🏠 / HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV / INPUT	📺 / SOURCE
MENU / LIST	-/--
DISPLAY	📺
SUBTITLE	📺
TEXT	📺
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
TIME SHIFT	SLEEP
TV / DVD	TV/DTV
TITLE	INFO
EPG	EPG
FAV	FAV
OPEN / CLOSE	⬆ / NET TV

ORIGINAL	SUPERIOR
PAUSE / STEP	⏸
STOP	■ / SMART
REC	RED
SCAN REW	GREEN
PLAY	YELLOW
SCAN FWD	BLUE
DVD	SHIFT+1
HDD	SHIFT+2
PR./CH+	SHIFT+ P+
PR./CH -	SHIFT+ P -
REPEAT	SHIFT+BACK
✓ / MARKER	SHIFT+FAV
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE	SHIFT+BLUE

