



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	AV
FUNCTION	-/--
DISPLAY	
EQ.	
SETUP	
 / S-TITLE	
VOLUME+	VOL+
VOLUME-	VOL-
SKIP NEXT/+	P+
SKIP PREV./-	P-
UP / PRESET+	UP
DOWN / PRESET-	DOWN
LEFT / TUN.-	LEFT
RIGHT / TUN.+	RIGHT
ENTER	OK
 / RETURN	BACK
SLEEP	SLEEP
HT. SPK.	TV/DTV
TITLE	INFO

[illegible]