



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VIRTUAL	/ SOURCE
SEARCH	-/--
DISPLAY	
ZOOM	
SETUP	
/ SUBTITLE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP+	P+
SKIP -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
SLEEP	SLEEP
*	TV/DTV
TITLE	INFO
PROG. MEMO	EPG

ORIGINAL	SUPERIOR
MARKER	FAV
OPEN / CLOSE	/ NET TV
PAUSE / STEP	
STOP	/ SMART
REW / SCAN -	GREEN
PLAY	YELLOW
FWD / SCAN+	BLUE
/ AUDIO	SHIFT+MUTE
DVD	SHIFT+1
USB	SHIFT+2
AUX	SHIFT+3
BAND	SHIFT+4
SOUND	SHIFT+
REPEAT	SHIFT+BACK
REPEAT A - B	SHIFT+SLEEP
XTS	SHIFT+INFO
DIMMER	SHIFT+EPG
RDS	SHIFT+FAV

