



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT NEXT	 / SOURCE
RDS	-/--
DISPLAY	
FUNCTION	
TITLE	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP/PRESET NEXT	UP
DOWN/PRESET PREV	DOWN
LEFT/TUNE DOWN	LEFT
RIGHT/TUNE UP	RIGHT
OK	OK
BACK	BACK
SLEEP	SLEEP
EQ.	INFO
PROGRAM/MEMO	EPG

[illegible]