



ORIGINAL	REPLACEMENT
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	AV
LIST	-/--
RATIO	
ASPECT	
SETUP	
NOT USED	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
NOT USED	SLEEP
MY MEDIA	TV/DTV
INFO	INFO

ORIGINAL	REPLACEMENT
Q.MENU	EPG
ENERGY SAVING	FAV
STILL	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
3D	SHIFT+3
USB	SHIFT+AV
KEystone UP	SHIFT+UP
KEystone DWN	SHIFT+DOWN
RETURN	SHIFT+BACK
PAUSE	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

