

| ORIGINAL                                                                                          | SUPERIOR                                                                                          |
|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| <b>DVD</b>                                                                                        |                                                                                                   |
| <b>POWER</b>                                                                                      | <b>POWER</b>                                                                                      |
|  / <b>AUDIO</b>    | <b>MUTE</b>                                                                                       |
| <b>DISC MENU / LIST</b>                                                                           | <b>MENU</b>                                                                                       |
| <b>CLEAR</b>                                                                                      | <b>EXIT</b>                                                                                       |
| <b>1/2/3/4/5</b>                                                                                  | <b>1/2/3/4/5</b>                                                                                  |
| <b>6/7/8/9/0</b>                                                                                  | <b>6/7/8/9/0</b>                                                                                  |
| <b>AV</b>                                                                                         |  / <b>SOURCE</b> |
| <b>DVD</b>                                                                                        | <b>-/--</b>                                                                                       |
| <b>DISPLAY</b>                                                                                    |                  |
| <b>ZOOM</b>                                                                                       |                  |
| <b>SETUP</b>                                                                                      |                  |
|  / <b>SUBTITLE</b> |                  |
| <b>SKIP NEXT</b>                                                                                  | <b>P+</b>                                                                                         |
| <b>SKIP PREV</b>                                                                                  | <b>P -</b>                                                                                        |
| <b>UP / PR/TRK+</b>                                                                               | <b>UP</b>                                                                                         |
| <b>DOWN / PR/TRK -</b>                                                                            | <b>DOWN</b>                                                                                       |
| <b>LEFT</b>                                                                                       | <b>LEFT</b>                                                                                       |
| <b>RIGHT</b>                                                                                      | <b>RIGHT</b>                                                                                      |
| <b>ENTER</b>                                                                                      | <b>OK</b>                                                                                         |
| <b>RETURN</b>                                                                                     | <b>BACK</b>                                                                                       |
| <b>A – B</b>                                                                                      | <b>SLEEP</b>                                                                                      |
| <b>TV / VCR</b>                                                                                   | <b>TV/DTV</b>                                                                                     |
| <b>TITLE</b>                                                                                      | <b>INFO</b>                                                                                       |

| ORIGINAL                                                                                  | SUPERIOR                                                                                  |
|-------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| SEARCH                                                                                    | EPG                                                                                       |
| VCR                                                                                       | FAV                                                                                       |
| OPEN / CLOSE                                                                              |          |
| PAUSE / STEP                                                                              |          |
| STOP                                                                                      |          |
| REC                                                                                       | RED                                                                                       |
| BACKWARD                                                                                  | GREEN                                                                                     |
| PLAY                                                                                      | YELLOW                                                                                    |
| FORWARD                                                                                   | BLUE                                                                                      |
| TIMER REC.                                                                                | SHIFT+SLEEP                                                                               |
| DUBBING                                                                                   | SHIFT+FAV                                                                                 |
| <b>VCR</b>                                                                                |                                                                                           |
| POWER                                                                                     | SHIFT+POWER                                                                               |
|  / AUDIO | SHIFT+MUTE                                                                                |
| DISC MENU / LIST                                                                          | SHIFT+MENU                                                                                |
| CLEAR                                                                                     | SHIFT+EXIT                                                                                |
| 1/2/3/4/5                                                                                 | SHIFT+ 1/2/3/4/5                                                                          |
| 6/7/8/9/0                                                                                 | SHIFT+ 6/7/8/9/0                                                                          |
| DISPLAY                                                                                   | SHIFT+  |
| PR / TRK+                                                                                 | SHIFT+ P+                                                                                 |
| PR / TRK -                                                                                | SHIFT+ P -                                                                                |
| DOWN                                                                                      | SHIFT+DOWN                                                                                |
| UP                                                                                        | SHIFT+UP                                                                                  |
| LEFT                                                                                      | SHIFT+LEFT                                                                                |

[illegible]