



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ INPUT	/ SOURCE
LIST	-/--
SIMPLINK	
RATIO	
Q. VIEW	
TEXT	
VOL+	VOL+
VOL -	VOL -
P/PAGE +	P+
P/PAGE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ BACK	BACK
TV / RAD	TV/DTV
INFO	INFO
GUIDE	EPG

ORIGINAL	SUPERIOR
FAV / MARK	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
ENERGY SAVING	SHIFT+POWER
Q. MENU	SHIFT+MENU
AV MODE	SHIFT+
SUBTITLE	SHIFT+
T. OPT.	SHIFT+
PAUSE	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

