



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
🏠 / HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT / TUNER	📺 / SOURCE
iPod	-/--
DISPLAY	📺
RESOLUTION	📺
SEARCH	📺
📄 / SUBTITLE	📄
VOL+	VOL+
VOL-	VOL-
SKIP NEXT	P+
SKIP PREV	P-
UP / PRESET NEXT	UP
DOWN / PRESET PREV.	DOWN
LEFT / TUN-	LEFT
RIGHT / TUN+	RIGHT
ENTER	OK
🔊 / RETURN	BACK
SLEEP	SLEEP
🔊 / SPK. LEVEL	TV/DTV
TITLE / POPUP	INFO

ORIGINAL	SUPERIOR
MARKER	FAV
OPEN / CLOSE	⬆️ / NET TV
PAUSE / STEP	⏸️
STOP	⏹️ / SMART
SCAN - REW	GREEN
PLAY	YELLOW
SCAN - FWD	BLUE
🎵 / SOUND	SHIFT+MUTE
DISC MENU	SHIFT+MENU
PIP	SHIFT+1
REPEAT	SHIFT+BACK
NIGHT	SHIFT+SLEEP
RED / A / RDS	SHIFT+RED
GREEN / B / PTY.	SHIFT+GREEN
YELL. / C / PTY. SEAR.	SHIFT+YELLOW
BLUE / D / MO./ST.	SHIFT+BLUE

