



| ORIGINAL     | SUPERIOR    |
|--------------|-------------|
| POWER        | POWER       |
| ⦿ / AUDIO    | MUTE        |
| DISC MENU    | MENU        |
| CLEAR        | EXIT        |
| 1/2/3/4/5    | 1/2/3/4/5   |
| 6/7/8/9/0    | 6/7/8/9/0   |
| AV           | 📺 / SOURCE  |
| RANDOM       | -/--        |
| DISPLAY      | 📺           |
| ZOOM         | 📺           |
| SETUP        | 📺           |
| ⦿ / SUBTITLE | 📺           |
| SKIP NEXT    | P+          |
| SKIP PREV    | P-          |
| UP           | UP          |
| DOWN         | DOWN        |
| LEFT         | LEFT        |
| RIGHT        | RIGHT       |
| ENTER        | OK          |
| 🔊 / RETURN   | BACK        |
| 📺 / ANGLE    | TV/DTV      |
| TITLE        | INFO        |
| PROGRAM      | EPG         |
| MARKER       | FAV         |
| OPEN / CLOSE | ⬆️ / NET TV |

| ORIGINAL     | SUPERIOR     |
|--------------|--------------|
| PAUSE / STEP | ⏸️           |
| STOP         | 📺 / SMART    |
| BACKWARD     | GREEN        |
| PLAY         | YELLOW       |
| FORWARD      | BLUE         |
| SEARCH       | SHIFT+EXIT   |
| DVD          | SHIFT+1      |
| VCR          | SHIFT+2      |
| REPEAT       | SHIFT+BACK   |
| A - B        | SHIFT+SLEEP  |
| TV           |              |
| POWER        | SHIFT+POWER  |
| MUTE         | SHIFT+MUTE   |
| AV           | SHIFT+📺      |
| VOL+         | SHIFT+ VOL+  |
| VOL -        | SHIFT+ VOL - |
| PR+          | SHIFT+ P+    |
| PR -         | SHIFT+ P -   |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |

