



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
RANDOM	-/--
DISPLAY	
GOTO	
SETUP	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
STEP	SLEEP
ANGLE	TV/DTV
TOP MENU / TITLE	INFO
SLOW	EPG

[illegible]