



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT	/ AV
LIST	-/--
PICTURE	
ZOOM	
SHIFT	
APPs	
VOL+	VOL+
VOL-	VOL-
PR.+	P+
PR.-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
← PR.	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
RED / FIND	RED
GREEN / V-FORMAT	GREEN
YELLOW / TXT	YELLOW
BLUE / 	BLUE
FAST FWD	SHIFT+ P+
FAST REW	SHIFT+ P-
PAGE+	SHIFT+UP
PAGE-	SHIFT+DOWN
TV / AV	SHIFT+TV
PAUSE	SHIFT+
STOP	SHIFT+
RECORD	SHIFT+RED
SLOW REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
SLOW FWD	SHIFT+BLUE
TV	
	SHIFT+POWER
SOURCE	SHIFT+ / AV
VOL+	SHIFT+ VOL+
VOL-	SHIFT+ VOL-

