



ORIGINAL	SUPERIOR
PWR	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
→ / TV/SAT	📺 / SOURCE
☰ / LIST	-/--
TEXT	☰
V+	VOL+
V-	VOL-
CH&PAGE/P+	P+
CH&PAGE/P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
↶ / BACK	BACK
🕒 / SLEEP	SLEEP
TV / RAD.	TV/DTV
INFO	INFO
EPG	EPG
📌 / MARK	FAV
SLOW	⏸

ORIGINAL	SUPERIOR
RED / OPT.	RED
GREEN / A/V+	GREEN
YELLOW / FAV	YELLOW
BLUE / A - Z	BLUE
F1	SHIFT+1
F2	SHIFT+2
↺ / A - B	SHIFT+BACK
📌 / JUMP	SHIFT+FAV
PAUSE	SHIFT+ ⏸
STOP	SHIFT+ ⏹
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FF	SHIFT+BLUE

