



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
DEFAULT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9	6/7/8/9
0 / 10	0
A – B	/ SOURCE
10+	-/--
DISPLAY	
ZOOM	
ANGLE	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
TIME	SLEEP
N/P	TV/DTV

ORIGINAL	SUPERIOR
TITLE	INFO
PROG.	EPG
P – SCAN	FAV
OPEN/CLOSE	/ MET TV
SLOW	
STOP	/ SMART
REV	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE
L/R	SHIFT+ -/--
SETUP	SHIFT+
LANGUAGE	SHIFT+
REPEAT	SHIFT+BACK
STEP	SHIFT+SLEEP
PBC	SHIFT+EPG

