



ORIGINAL	SUPERIOR
ON – STANDBY	POWER
MUTE	MUTE
OPTION	MENU
CBL/SAT	1
DVD	2
BLU – RAY	3
GAME	4
AUX	5
MEDIA PLAYER	6
TV AUDIO	7
CD	8
TUNER	9
IPOD/USB	0
M – XPORT	⏏ / SOURCE
PHONO	-/--
SETUP	⏏
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT/TUNE+	P+
SKIP PREV/TUNE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK

ORIGINAL	SUPERIOR
BACK	BACK
SLEEP	SLEEP
INFO	INFO
INTERNET RADIO	⬆ / NET TV
NETWORK	⬇ / SMART
PLAY/PAUSE	YELLOW
FAVORITE STATION 1	SHIFT+1
FAVORITE STATION 2	SHIFT+2
FAVORITE STATION 3	SHIFT+3
CH/PAGE+	SHIFT+ P+
CH/PAGE -	SHIFT+ P -
RED / HOME	SHIFT+RED
GREEN / MUSIC	SHIFT+GREEN
BLUE / GAME	SHIFT+BLUE
YELLOW / PURE	SHIFT+YELLOW

