



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT / MOVIES	-/--
PHOTOS	
MUSIC	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
RED / VIDEO FORMAT	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE / TIMER	BLUE
AUDIO	SHIFT+MUTE
SEARCH	SHIFT+EXIT
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAGE+	SHIFT+UP
PAGE -	SHIFT+DOWN
REC TV	SHIFT+FAV
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

