



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV SYSTEM	-/--
GOTO	
SETUP	
SUB – T	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
MUSIC	SLEEP
MOVIE	TV/DTV
INFO	INFO
PHOTO	FAV
STOP	 / SMART VIDEO
REW	GREEN

[illegible]