



| ORIGINAL     | SUPERIOR  |
|--------------|-----------|
| POWER        | POWER     |
| MUTE         | MUTE      |
| MENU         | MENU      |
| CLEAR        | EXIT      |
| 1/2/3/4/5    | 1/2/3/4/5 |
| 6/7/8/9/0    | 6/7/8/9/0 |
| SOURCE       | / AV      |
| +10          | -/--      |
| ANGLE        |           |
| ZOOM         |           |
| SETUP        |           |
| TITLE        |           |
| VOL+         | VOL+      |
| VOL-         | VOL-      |
| SKIP NEXT    | P+        |
| SKIP PREV.   | P-        |
| UP           | UP        |
| DOWN         | DOWN      |
| LEFT / FAV-  | LEFT      |
| RIGHT / FAV+ | RIGHT     |
| ENTER        | OK        |
| PROGRAM      | BACK      |
| STEP         | SLEEP     |
| PBC          | TV/DTV    |
| VIDEO        | INFO      |

| ORIGINAL     | SUPERIOR     |
|--------------|--------------|
| RETURN       | EPG          |
| LANGUAGE     | FAV          |
| OPEN / CLOSE |              |
| PAUSE        |              |
| STOP         |              |
| REC          | RED          |
| REW          | GREEN        |
| PLAY         | YELLOW       |
| FWD          | BLUE         |
| TIME         | SHIFT+POWER  |
| SUBTITLE     | SHIFT+       |
| REPEAT       | SHIFT+BACK   |
| SLOW         | SHIFT+SLEEP  |
| OSD          | SHIFT+TV/DTV |
| A – B        | SHIFT+INFO   |
| N / P        | SHIFT+EPG    |
| L / R        | SHIFT+FAV    |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |
|              |              |

