



ORIGINAL	REPLACEMENT
ON / STANDBY	POWER
MUTING	MUTE
SETUP	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SP. A/B	AV
-/-- / 10 / DIMMER	-/--
DISPLAY	
VOL+	VOL+
VOL-	VOL-
PRESET NEXT	P+
PRESET PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
LI. MODE – MOVIE/TV	RED
LIST. MODE – MUSIC	GREEN
LISTEN. MODE – GAME	YELLOW
LIST. MODE – STEREO	BLUE
AUDIO	SHIFT+MUTE
INPUT SEL. – AUX	SHIFT+1

[illegible]