



ORIGINAL	REPLACEMENT	ORIGINAL	REPLACEMENT
POWER	POWER	GREEN	GREEN
MUTE	MUTE	YELLOW	YELLOW
MENU	MENU	BLUE	BLUE
EXIT	EXIT	AUDIO	SHIFT+MUTE
1/2/3/4/5	1/2/3/4/5	STOP	SHIFT+ [Red Square]
6/7/8/9/0	6/7/8/9/0	REC	SHIFT+RED
AV	AV	REW	SHIFT+GREEN
-/--	-/--	PLAY/PAUSE	SHIFT+YELLOW
GOTO	[TV Icon]	FWD	SHIFT+BLUE
SUBTITLE	SHIFT+ [Text Icon]		
FILE	[Text Icon]		
TXT	[Text Icon]		
VOL+	VOL+		
VOL-	VOL-		
P+	P+		
P-	P-		
UP	UP		
DOWN	DOWN		
LEFT	LEFT		
RIGHT	RIGHT		
OK	OK		
RECALL	BACK		
INFO	INFO		
LANG	FAV		
RED	RED		

