



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
M / P	-/--
FIND	
TEXT	
VOL+	VOL+
VOL -	VOL -
	P+
	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
SLEEP	SLEEP
TV / STB	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV
V. FORMAT	/ NET TV

ORIGINAL	SUPERIOR
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SAT LIST	SHIFT+ -/--
ZOOM	SHIFT+
SUBTITLE	SHIFT+
SLOW	SHIFT+ P+
REV SLOW	SHIFT+ P -
TV / RADIO	SHIFT+ TV/DTV
DVR INFO	SHIFT+INFO
PAUSE	SHIFT+
STOP	SHIFT+
RECORD	SHIFT+RED
FB	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FF	SHIFT+BLUE

