



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
ON DEMAND	/ SOURCE
PLAYLIST	-/--
MY ACCOUNT	
OPTIONS	
TXT	
V+	VOL+
V -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
TV	TV/DTV
INFO	INFO
TV GUIDE	EPG

ORIGINAL	SUPERIOR
FAVORITES	FAV
RED / BOOKMARK	RED
GREEN / HELP	GREEN
YELLOW / SUBTITLES	YELLOW
BLUE / LANGUAGE	BLUE
APPS / GAMES	SHIFT+8
	SHIFT+OK
RADIO	SHIFT+ TV/DTV
EXTRA	SHIFT+FAV
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

