



ORIGINAL	SUPERIOR
	POWER
AUDIO	MUTE
MENU / PLAY LIST	MENU
CANCEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV ENHANCER	 / AV
>10	-/--
PICTURE MODE	
ZOOM	
SETUP	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
MANUAL SKIP	SLEEP
GROUP	TV/DTV
FUNCTIONS	INFO
ANGLE / PAGE	EPG
TOP MENU / D. NAV.	FAV

[illegible]