



| ORIGINAL                                                                                  | SUPERIOR                                                                                    |
|-------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| DVD POWER                                                                                 | POWER                                                                                       |
| A / AUDIO                                                                                 | MUTE                                                                                        |
| TOP MENU / DIR. NAV.                                                                      | MENU                                                                                        |
| CANCEL / *                                                                                | EXIT                                                                                        |
| 1/2/3/4/5                                                                                 | 1/2/3/4/5                                                                                   |
| 6/7/8/9/0                                                                                 | 6/7/8/9/0                                                                                   |
| INPUT SELECT                                                                              |  / SOURCE  |
| VIDEO PLUS+                                                                               |            |
| FUNCTIONS                                                                                 |            |
| SKIP NEXT                                                                                 | P+                                                                                          |
| SKIP PREV                                                                                 | P -                                                                                         |
| UP                                                                                        | UP                                                                                          |
| DOWN                                                                                      | DOWN                                                                                        |
| LEFT / STEP BACK                                                                          | LEFT                                                                                        |
| RIGHT / STEP FWD                                                                          | RIGHT                                                                                       |
| ENTER                                                                                     | OK                                                                                          |
| RETURN                                                                                    | BACK                                                                                        |
|  / TIMER | SLEEP                                                                                       |
| DIRECT TV REC.                                                                            | TV/DTV                                                                                      |
| INFO                                                                                      | INFO                                                                                        |
| PROG. / CHECK                                                                             | EPG                                                                                         |
| REC. MODE                                                                                 | FAV                                                                                         |
| PAUSE                                                                                     |          |
| STOP                                                                                      |  / SMART |
| REC                                                                                       | RED                                                                                         |

[illegible]