



ORIGINAL	SUPERIOR
	POWER
AUDIO	MUTE
HOME	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DISPLAY	
OPTION	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT / ◀ 	LEFT
RIGHT / ▶	RIGHT
OK	OK
 / RETURN	BACK
POP-UP MENU	TV/DTV
STATUS	INFO
SKYPE	EPG
TOP MENU	FAV
OPEN / CLOSE	 / NET TV
PAUSE	
STOP	 / SMART
SLOW/SEARCH REW	GREEN
PLAY	YELLOW

[illegible]