



ORIGINAL	SUPERIOR
	POWER
AUDIO	MUTE
TOP MENU/POP-UP MENU	MENU
X/EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MIRACAST	 / SOURCE
#	-/--
HOME	
STATUS	
OPTION	
 / CC	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
 / RETURN	BACK
INTERNET	TV/DTV
PIP	EPG
NETFLIX	 / NET TV
PAUSE	 / SMART TUBE
STOP	 / SMART VIDEO

[illegible]