



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU/PLAYLIST	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
>10	-/--
OSD	
SUB – WOOFER LEVEL	
FUNCTIONS	
TEST	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK/SETUP	BACK
SLEEP/DISPLAY	SLEEP
CENTRE FOCUS	INFO
EQUALIZER	EPG
PLAY MODE/CH. SEL.	FAV

[illegible]