



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU / PLAYLIST	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INP. NEXT/INP. RADIO	 / SOURCE
>10	-/--
FUNCTIONS	
VOL+	VOL+
VOL -	VOL -
SKIP/PRESET PREV	P+
SKIP/PRESET NEXT	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
SLEEP / FL DISPLAY	SLEEP
START	INFO
WHISPER MODE	EPG
SURROUND	FAV
PAUSE	
STOP	 / SMART

[illegible]