



ORIGINAL	SUPERIOR	ORIGINAL	SUPERIOR
PWR	POWER		
AUDIO	MUTE		
MENU / TITLE	MENU		
1/2/3/4/5	1/2/3/4/5		
6/7/8/9/0	6/7/8/9/0		
REPEAT	-/--		
SUBTITLE			
SKIP NEXT	P+		
SKIP PREV.	P-		
UP	UP		
DOWN	DOWN		
LEFT	LEFT		
RIGHT	RIGHT		
ENTER	OK		
RETURN	BACK		
TRK/GRP/TITLE/CHAPTER	INFO		
ANGLE	EPG		
PAUSE			
STOP			
PLAY	YELLOW		

