



ORIGINAL	REPLACEMENT
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AUDIO	SHIFT+MUTE
LIST	-/--
GOTO	
V.FORMAT	
NOT USED	
TEXT	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TIMER	SLEEP
TV/RADIO	TV/DTV
INFO	INFO

ORIGINAL	REPLACEMENT
GUIDE	EPG
FAV	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
SUBTITLE	SHIFT+
SKIP NEXT CHAP	SHIFT+P+
SKIP PREV CHAP	SHIFT+P-
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE
REPEAT	SHIFT+BACK

