



ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
/ EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SOURCES	/ SOURCE
/ LIST	-/--
/ OPTIONS	
TEXT	
VOL+	VOL+
VOL -	VOL -
+	P+
-	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ BACK	BACK
/ INFO	INFO
/ TV GUIDE	EPG
/ FORMAT	/ NET TV
RED	RED
GREEN	GREEN

ORIGINAL	SUPERIOR
YELLOW	YELLOW
BLUE	BLUE
/ SETUP	SHIFT+
SUBTITLE	SHIFT+
FWD	SHIFT+ P+
REW	SHIFT+ P -
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

