



ORIGINAL	SUPERIOR
	POWER
	MUTE
/ MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SOURCE	/ SOURCE
12	-/--
AMBILIGHT	
TELETEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ BACK	BACK
CLOCK	SLEEP
INFO	INFO
/ GUIDE	EPG
MODE	FAV
RED / DEMO	RED

ORIGINAL	SUPERIOR
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
SUBTITLE	SHIFT+
P ↔ P	SHIFT+BACK
STOP / CANCEL	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE
HTS	
	SHIFT+MUTE
VOL+	SHIFT+ VOL+
VOL -	SHIFT+ VOL -

