



ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
 / SOURCE	 / SOURCE
 / LIST	-/--
 / OPTIONS	
TEXT	
+	VOL+
-	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
 / TV	TV/DTV
i / INFO	INFO
 / FORMAT	 / NET TV
RED	RED
GREEN	GREEN
YELLOW	YELLOW

[illegible]