



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
X	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	/ SOURCE
-/--	-/--
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
BRIGHTNESS+	UP
BRIGHTNESS -	DOWN
COLOR -	LEFT
COLOR+	RIGHT
PP	OK
P ← P	BACK
	SLEEP
WHITE / E / INFO	INFO
	FAV

ORIGINAL	SUPERIOR
INSTALL / ◇◇	/ NET TV
RED / A	RED
GREEN / B	GREEN
YELLOW / C	YELLOW
BLUE / D	BLUE
POWER (BLACK)	SHIFT+POWER
?	SHIFT+1
?	SHIFT+2
OFF	SHIFT+0
SOURCE 2	SHIFT+
	SHIFT+
	SHIFT+
	SHIFT+
	SHIFT+
	SHIFT+DOWN
	SHIFT+UP
- Y	SHIFT+LEFT
+ >>>	SHIFT+RIGHT
PIP+	SHIFT+ P+
PIP -	SHIFT+ P -
	SHIFT+SLEEP
	SHIFT+INFO

