



ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
TV / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SOURCES	/ SOURCE
/ LIST	-/--
/ AMBILIGHT	
/ SETTINGS	
TEXT	
+	VOL +
-	VOL -
+	P +
-	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
/ TV GUIDE	EPG
TOP PICKS	FAV
NETFLIX	/ NET TV
RED	RED

ORIGINAL	SUPERIOR
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
+	SHIFT+MENU
/ SEARCH	SHIFT+EXIT
SUBTITLE	SHIFT+
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

