



ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
 / SOURCE	 / SOURCE
 / LIST	-/--
AMBILIGHT	
 / FORMAT	
OPTIONS	
TEXT	
+	VOL+
-	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
 / TV	TV/DTV
i / INFO	INFO
GUIDE	EPG

[illegible]