



ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
TV / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	/ SOURCE
	-/--
TEXT	
+	VOL+
-	VOL -
+	P+
-	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
←	BACK
AMBILIGHT	SLEEP
i	INFO
	EPG
NETFLIX	/ NET TV
RAKUTEN TV	/ SMART TUBE

ORIGINAL	SUPERIOR
	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

