



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
TV/EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	 / SOURCE
DISNEY+	-/--
AMBILIGHT	
	
OPTIONS	
SUBTITLE	
+	VOL+
-	VOL -
+	P+
-	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
CHANNELS	SLEEP
	TV/DTV
INFO	INFO

[illegible]