



ORIGINAL	SUPERIOR	ORIGINAL	SUPERIOR
	POWER		
MUTE	MUTE		
MENU	MENU		
SCAN	EXIT		
SOURCE	 / SOURCE		
CLOCK	-/--		
VOL+	VOL+		
VOL -	VOL -		
SKIP NEXT	P+		
SKIP PREV	P -		
PRESET/ALBUM+	UP		
PRESET/ALBUM -	DOWN		
OK	OK		
REPEAT/SHUFFLE	BACK		
TIMER/SLEEP	SLEEP		
DIM	TV/DTV		
RDS/INFO	INFO		
PROG	EPG		
SOUND	FAV		
EJECT	 / NET TV		
STOP	 / SMART		
PLAY/PAUSE	YELLOW		

