



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
HOME	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SUBTITLE	
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
OPTIONS	EPG
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
POP – UP MENU	SHIFT+MENU
TOP MENU	SHIFT+EXIT
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REW	SHIFT+GREEN

[illegible]