



ORIGINAL	SUPERIOR
	POWER
AUDIO	MUTE
DISC MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
USB	 / AV
HOME	
ZOOM	
OPTIONS	
SUBTITLE	
TV VOL+	VOL+
TV VOL-	VOL-
SKIP NEXT	P+
SKIP PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
 / BACK	BACK
INFO	INFO
GUIDE PLUS+ / TIMER	EPG
LIVE TV	FAV
EJECT	
STOP	

[illegible]