



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
HDD	 / SOURCE
	-/--
VIDEO FORMAT	
TEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK / P<P	BACK
RADIO	TV/DTV
INFO	INFO
EPG / GUIDE	EPG
FAV / LIST	FAV
RED	RED

[illegible]