



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU / EXIT	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
CH - LIST	-/--
/ PICTURE	
/ SOUND	
MIX	
TELETEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
PRE. CH.	BACK
SLEEP	SLEEP
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
ZOOM	/ NET TV
AD	/ SMART TUBE
HOLD	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
DUAL I-II	SHIFT+MUTE
TV	SHIFT+1
HDMI	SHIFT+2
VIDEO	SHIFT+3
PC	SHIFT+4
FREEZE	SHIFT+ -/--
✓ / REVEAL	SHIFT+
SIZE	SHIFT+
SUBTITLE	SHIFT+
SUBPAGE	SHIFT+DOWN
INDEX	SHIFT+INFO

