



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
X	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	 / SOURCE
P>P -/--	-/--
	
	
	
	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
PP	TV/DTV
?	INFO
	EPG
WHITE / E	FAV
RED / A	RED
GREEN / B	GREEN
YELLOW / C	YELLOW
BLUE / D	BLUE
	SHIFT+MUTE

[illegible]