



ORIGINAL	SUPERIOR
SUPERIOR HOTEL TV	
TV+	POWER
	MUTE
----	SMART
----	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
----	GUIDE
/ TEXT	TXT
UP	UP
LEFT	LEFT
OK	OK
RIGHT	RIGHT
DOWN	DOWN
VOL+	VOL+
VOL -	VOL -
TV+	CH+
TV -	CH -
/ ALARM ON	INFO
SMART	SOURCE

ORIGINAL	SUPERIOR
SUPERIOR SIMPLY DIGITAL TV	
TV+	POWER TV
DTT FUNCTION	POWER DTT
DTT FUNCTION	MENU
DTT FUNCTION	SMART
DTT FUNCTION	EXIT
DTT FUNCTION	1/2/3/4/5
DTT FUNCTION	6/7/8/9/0
DTT FUNCTION	GUIDE
DTT FUNCTION	TXT
DTT FUNCTION	UP
DTT FUNCTION	LEFT
DTT FUNCTION	OK
DTT FUNCTION	RIGHT
DTT FUNCTION	DOWN
VOL+	VOL+
VOL -	VOL -
DTT FUNCTION	CH+
DTT FUNCTION	CH -
DTT FUNCTION	INFO
DTT FUNCTION	SOURCE
DTT FUNCTION	MUTE

