



ORIGINAL	SUPERIOR
	POWER
	MUTE
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	/ SOURCE
-/-- / P < P	-/--
/ SMART PICTURE	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
DNR	BACK
	SLEEP
12	TV/DTV
i+	INFO
	EPG
/ WHITE	FAV

ORIGINAL	SUPERIOR
	/ NET TV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
/ SMART SOUND	SHIFT+MUTE
	SHIFT+
/ ZOOM	SHIFT+
I - II	SHIFT+
	SHIFT+
	SHIFT+EPG
INSTANT REC	SHIFT+FAV
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

