



ORIGINAL	SUPERIOR
	POWER
	MUTE
SETTINGS	MENU
EXIT / WHITE	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	/ AV
	-/--
/ SMART	
/ DIGITAL SETUP	
/ TEXT	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
SELECT	OK
P < P	BACK
	SLEEP
i+	INFO
GUIDE	EPG

ORIGINAL	SUPERIOR
	FAV
INSTANT REC	
INSTANT STOP	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
/ SMART	SHIFT+MUTE
	SHIFT+
	SHIFT+
DNR	SHIFT+INFO
I – II	SHIFT+FAV
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

