



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU / BROWSE	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
 / SOURCE	 / SOURCE
MHEG / CANCEL	-/--
OPTION	
	
P ↔ P	
TELETEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT / BACK	LEFT
RIGHT	RIGHT
OK	OK
INFO	INFO
 / GUIDE	EPG
RED / DEMO	RED
GREEN	GREEN

[illegible]